

Tips for getting the most out of your home WiFi

Position your WiFi router or gateway like a pro:

- A WiFi router or gateway connects all your devices to the Internet. Positioning it in the wrong place could result in slower speeds and spotty coverage.
- Check the position of your router or gateway— place it in an open, centralized location close to where you use your devices and away from tight spaces like corners. Avoid placing it in a closet, cabinet, the basement, behind a concrete wall, in a tight corner, or between books.



Update devices and regularly reboot your router or gateway:

- Regularly update device software and restart your router or gateway. If you're using an older device, then it might be time to get a new one.

Create distance from electronic devices:

- Don't place your router or gateway too close to any devices that might interfere with it, such as a baby monitor, a microwave, Bluetooth speakers, or other electronics

Hardwire devices:

- Try hardwiring the devices you use the most directly to your router or gateway using an Ethernet cable to get the fastest speeds.

Get speed for every device:

- Internet speed is shared across all devices in your home, so the more devices you have, the more speed you may need.

Get coverage where you need it:

- Use WiFi extenders to eliminate spotty WiFi coverage and deadspots.

